



TeleScript AV or TeleScript Pro XK12 Controller Functions

1. Next Script — Edit/Prompt, load and display the Next Script in run order
2. Previous Script — Edit/Prompt, load and display the Previous Script in run order
3. MEM — Edit or Prompt: Memorize the line at the index arrow
4. Edit Mode — Prompt: Go to Edit Mode
5. Stop (Scroll) — Prompt: Stop scrolling (index arrow red)
6. RCL — Edit or Prompt: Recall the memorized location and place at index arrow
7. QuickZoom — Edit or Prompt: Zoom out by the specified ratio, then Zoom In, with cursor at edit point
8. Go (Scroll) — Prompt: Start scrolling
9. Prompt Mode — Edit: Got to Prompt Mode
10. Display/Hide Runlist — Edit/Prompt: Display or Hide the runlist.
11. Next Bookmark — Edit/Prompt: Go to next bookmark and set MEM to this location.
12. Previous Bookmark — Edit/Prompt: Go to previous bookmark and set MEM to this location.
13. Digital Pot — Prompt: Speed Control
14. Spring Loaded Outer Ring: Prompt: Prompter Green or Yellow Index Arrow, jog forward or backward, then Idle